



Electronic Balance
Model YR01761
Service Manual



1. Linear Calibration

1) When the machine is in Off status, first press **CAL**, second short press , then take off , keep pressing **CAL**, until LCD display **CAL 0**, take off **CAL**, keep the condition warm up two minutes;


2) Load

After warm up two minutes, LCD still display **CAL 0**, quickly placed the full load, then quickly take off the full load.


3) Linear Calibration

Press **CAL**, LCD display “-----”, then jump the first value (value jumping), load the corresponding weights, waiting for a sign “-----”, when LCD jump the second value, remove the weights; load the corresponding weights, still waiting for a sign “-----”, then LCD jump the next value, remove weights; Repeat operate to final value, the Beeper will sound “di di di.....”, then remove the full weights, linear calibration is ok.

2. The function setting(Use factory settings).default:3515250

1) Press  3sec, enter function setting, LCD display **USE-SET**(USE-SET), then display **8888888**.

2) Press  to set numerical data, press  to change the digital position, according to the follow

Picture to set proportional value, then press  to confirm.

Picture: Set numerical data with (a)、(b)、(c)、(d)、(e)、(f)、(g) as follow:

- (a) Filter range:0~9 The higher the value, the better the filtering
- (b) Filter resistance: 0~9 The higher the value, the better the filtering
- (c) Filter retardation: 0~9 The higher the value, the better the filtering
- (d) Zero tracking range: 0~9 equal 0.0~ 0.9d
- (e) Auto zero range: 0~9 equal 0~ 9d
- (f) Load the weight auto zero range: 0~9 equal 0~ 9d
- (g) Auto turn off setting:
0= no, 1=5min, 2=10min, 3=30min.